


Transmitter Preparation








Transmitter Battery Installation

Open battery cover at the bottom of the transmitter. Install batteries. Follow the direction of batteries designated in the inside of battery box.




AA Batteries



Setup Before Starting

Turn on transmitter first,
then turn on receiver.



Make sure no one else is using the same radio frequency as you are using. Check the radio system and range before every driving session. To properly check the range, have a friend hold the buggy with the engine off and walk to the farthest distance that you plan to operate your model. Operate the controls to make sure the model responds correctly. Do not operate the model if there is any problem with the radio system.

